

INSTALLATION INSTRUCTIONS

For Frosted Window Film



INSTALLATION KIT CONTENTS:

Window vinyl (cut to specified measurements).
Spray bottle containing application fluid.
Plastic squeegee.

INSTRUCTIONS:

DO:

Clean your hands.
Clean the glass with soapy water and a lint free cloth, removing dust, dirt and grease.
Apply the vinyl to flat and smooth glass only.
Apply the vinyl from the inside of the room.

DON'T:

Work on carpet.
Wear clothes with loose fibres.
Remove the application tape prior to installation.
Apply the vinyl in strong sunlight.

STEPS:

1:

Unroll the vinyl with the backing paper side up onto a flat, clean and dry surface.
Remove the backing paper, taking care not to crease the vinyl.

2:

Spray a light mist of the application fluid to the adhesive side of the vinyl.

3:

Spray the window liberally with the same application fluid.

4:

Carefully take hold of the vinyl by the two top corners and carry over to the window.

5:

Offer the adhesive side of the vinyl to the glass surface and manoeuvre into position.
Gently press the vinyl into place.

6:

Use the plastic squeegee to expel trapped air and fluid from the centre outward.
If bubbles remain, repeat this step.

7:

Leave the vinyl to settle for 3-4 hours. When the window is dry and the vinyl is fully adhered you may remove the application tape. If bubbles are present around the cut out areas, repeat step 6.

*The window vinyl will be thoroughly fixed after 24 hours.
You may clean your windows as normal but avoid using hard edged objects upon contact.*

TO REMOVE THE FILM:

Make sure the glass is not cold. Apply hot water to your window with a sponge. Starting from a corner, slowly peel the vinyl away. Clean the glass with a window scraper and methylated spirit.